

OUTBACK KITTERS

OK131007-K OUTBACK KITTERS Turn Signal / Indicator CANBUS Relay

FORD F-150 (15-24)

CONTENTS	TOOLS NEEDED
1x OK131007 Indicator Patch Harness CANBUS Relay 1x OK131027 Indicator Relay Base 1x CANBUS Turn Relay 1x 2 Pin Female Connectors (2x for Turn Signal)	- Electrical Pliers - Terminal Crimpers

TIME	DIFFICULTY
1 HOUR	EASY

IMPORTANT NOTES
Does not connect DRL

FAILURE TO INSTALL THIS PRODUCT AS SPECIFIED IN THE INSTALLATION PROCEDURE WILL VOID ALL WARRANTY. IF ANY PARTS HAVE ARRIVED DAMAGED OR WERE NOT SUPPLIED, PLEASE TAKE PHOTOS AND CONTACT YOUR SUPPLIER.

Step 1

Locate the fuse panel on the Drivers side footwell.



Step 2

Remove the cover and locate the cable loom behind the OBDII port.



Step 3

Carefully remove the loom tape wrapped around the cables and locate the Blue, White twisted cables.



Step 4

A) Using the provided splice terminals, connect the blue wire with the blue wire and the white wire with the white wire.

CAN Low - Blue

CAN High - White

25+ Models

CAN Low wire is grey/blue stripe and the CAN High wire is green/orange stripe

B) Ensure that the crimp is firmly pressed down and the cover closes properly over the terminal.

IMPORTANT NOTE

PLEASE ENSURE THAT THE CRIMP IS FIRMLY PRESSED DOWN. IT HAS BEEN FLAGGED BY CUSTOMERS THAT THE RELAY DOES NOT WORK, BUT THIS WAS RESOLVED BY FIRMLY PRESSING DOWN THE CRIMP.



Step 5

- A) Locate the 7.5amp (Number 3) fuse.
- B) Earth the black cable to a local earth point on the body.
- C) Using the provided Fuse tap, remove the factory fuse and replace it with the fuse tap.



Step 6

Secure the CANBUS relay using a zip tie up behind the dash.